



A2-Nord	
WA	III
o	
GRZ 0,4	

A2-Süd	
WA	III
a	
GRZ 0,35	

A1-Nord	
WA	III
o	
GRZ 0,4	

A1-Süd	
WA	III
a	
GRZ 0,35	

A4	
WA	III
a	
GRZ 0,35	

A9	
MI	V
g	
GRZ 0,6	

A10	
WA	V
g	
GRZ 0,4	

A3	
WA	III
a	
GRZ 0,35	

A6	
WA	III
o	
GRZ 0,4	

A5	
WA	III
a	
GRZ 0,35	

B1-Nord	
WA	III
o	
GRZ 0,4	

B1-Süd	
WA	III
a	
GRZ 0,35	

B2	
WA	III
a	
GRZ 0,35	

B5	
WA	III
o/a	
GRZ 0,4	

B3	
WA	III
a	
GRZ 0,35	

B4	
WA	II
a	E/D
GRZ 0,25	